


Elite

DOUBLE SIDE EXPOBAN 24008025


Assemble Instruction



1. Place one end of the threaded Rod (2) in the Base Support (1) and one Screw (6).




2. Repeat the same procedure throughout the 4 corners of the base.



3. Place Base on the floor and insert the Fiberglass Rods (4) into both ends of the Base.



5. Stick the adhesive strips over the top and bottom side of the image banner.



6. Fold the borders in and slide them into the Aluminum Rods.



4. On the top side, joint the 2 metal connectors (5) to the Fiberglass Rods (4)



8. Extend the image banner and put the bottom Aluminum Rod (3) through the spring of the Base (1) to maintain the image banner stretched out. Repeat the same process for the other side.



7. Lean the Top Rod (3) over the metal connectors (5).

Parts and accessories

1. Two Base Supports with springs
2. Two Rods for the base with threaded ends on both sides
3. Four Aluminum Rods with adhesive strips
4. Four Fiberglass Rods
5. Two Connectors for top Aluminum Rods and Fiber Glass Bars
6. Four Screws for the base

Note: : The width of the banner is not adjustable (31"), the height is adjustable by shortening the lateral fiberglass rods (3) to desired height.