

Elite

X TYPE EXPOBAN B 24008027


Assemble Instruction




1. Print the image banner to required size and place grommets (4) on each corner; make sure grommets are not too big.



2. Extend Base (1) through on the floor.



3. Place Fiberglass Rods (2) and Fiberglass Extensions (3) on each side.



4. Insert image banner on each corner by securing it to the Expoban with the supplied bolts (4) to keep in place.



Note: The size of the banner shall be 33" wide, up to a maximum of 78" high. Smaller measurements can be set in by shortening Rods (2) or by eliminating the extensions (3) in accordance to desired size.

Parts and accessories

1. One Fiberglass Tripod Base.
2. Two Fiberglass Rods
3. Two Fiberglass Extensions
4. Four Screws and small size grommets